

Mitre-Mite®

VN144S Operating Manual

***** Quick Guide *****

Version B



AMP

A Fletcher Company

859 West End Court - Unit 103 - Vernon Hills, IL 60061

Phone - 800-322-4204 Fax - 800-426-7019

TABLE OF CONTENTS

1.0	INITIAL START-UP AND USE OF THE MACHINE	3
1.1.	WORKSTATIONS AND OPERATORS' TASKS.....	4
1.2.	SWITCH-ON - CONTROLS - CHECKS - ADJUSTMENTS - START-UP.....	6
	1.2.1.START-UP	6
	1.2.1.MECHANICAL ADJUSTMENTS / MAINTENANCE	7
1.3.	WORK CYCLE	24
1.4.	DEACTIVATION	25
1.5.	MECHANICAL SCHEMATIC.....	26
1.6.	PNEUMATIC SCHEMATIC.....	32

1.0 INITIAL START-UP AND USE OF THE MACHINE



The machine must only be operated by authorized and duly trained personnel with adequate technical experience.



The personnel assigned to operate the machine must be aware of the fact that the knowledge and application of safety rules is an integral part of their work.

Unqualified personnel must not gain access to the operating area while the machine is being used.

Before switching on the machine:

Carefully read the technical documentation;

know which protective equipment and emergency devices are available on the machine, where they are located, and how they work. (note: protection safety guard kit is available and can be ordered through your authorized distributor or direct from manufacturer)

The partial removal of the guards (optional, if equipped) and warning signs is forbidden.

Unauthorized use of commercial parts and accessories belonging to the guards and safety devices (optional, if equipped) can result in malfunctions and the occurrence of dangerous situations for operators.



Before starting the production cycle the operator must perfectly know: the position, function and use of all commands;



the position, function and use of all safety devices; the characteristics of the machine;

be entirely familiar with this manual, and know how to consult it.

Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- **Disconnect main air supply from machine**
- **Release “PLV” switch to “off” (page 7 – figure A)**
- **Make sure foot pedal is away from any type of activation**

1.1. WORK STATIONS AND OPERATORS TASKS



The machine described herein is designed to be run by 1 operator, suitably trained and instructed with regard to residual risks, with the same safety skills as the maintenance technicians, and with the professional skills.

The normal work zone of the operator and relevant tasks/assignments are:

- i. the manual introduction/removal of the rods in the work surface,
- ii. the manual loading of the v-nails in the magazine,
- iii. the adjustments and tooling of the main machine units (nail head, handles, angle gauges, etc.) needed to use the machine, using the special tools,
- iv. the manual removal of any v-nails jammed in the magazine and nail head,
- v. operating checks: these are easy, carried out in safe conditions, and are clearly explained in the Operating Manual;
- vi. normal machine operation, i.e. stopping and starting the machine in normal conditions, and stopping it in emergency conditions;
- vii. general surveillance during machine operation (for example checking the cleanliness of the machine, etc). If there is a problem, operator must not intervene until machine has been put in maintenance state which means main air supply has been disconnected.
- viii. cleaning external and internal machine parts, and any other part that requires cleaning (e.g. the upper/surrounding part of the counter-rotating mechanics) via the cleaning of internal machine parts, is the responsibility of the maintenance technician and should be performed only when machine has been put in maintenance state which means main air supply has been disconnected.

In addition, the operator must supervise machine operation and running, moving freely around it, within the safety areas and with the guards closed.

The operator is responsible for the machining process, and must command the machine by means of the command actuators located in the control panels.

Apart from normal machine operation, the operator must also start and stop the machine in normal conditions, and stop it in emergency conditions.

The operator must also carry out checks and general surveillance while the machine is running. If there is a problem, he must not intervene, but simply call the maintenance service.

All operations that are carried out by the operator must be carried out with all the protection devices activated, any guards in place, and all the safety devices engaged; otherwise there is a risk of injury to arms, legs and other body parts.



All handling, preparation, adjustment, installation and connection of the power supplies, along with fine tuning and operating checks must be carried out by trained, skilled maintenance personnel.



All maintenance and control operations must be carried out by trained and skilled maintenance personnel.

All installation and connection operations, and any other operations indicated must be carried out using suitable equipment and tools of suitable dimensions (e.g. a flathead or Phillips screwdriver, hexagonal spanners, Allen spanner, etc.), depending on the screws.


Before carrying out any installation or connection operation, the machine and its components must be thoroughly cleaned.

The main dangerous working areas of the machine, that may produce risks for the operator, are:

- i. area beneath the pad of the vertical clamp unit;
- ii. area in front of the frontal clamp;
- iii. inside of the machine during adjustment, tooling and cleaning operations.

Schematic diagram showing the dangerous work areas for the machine installer:

- A. area beneath the pad of the vertical clamp unit.
- B. area in front of the frontal rod clamp.



Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- ☐ Disconnect main air supply from machine
- ☐ Release “PLV” switch to “off” (page 7 – figure A)
- ☐ Make sure foot pedal is away from any type of activation

1.2. SWITCH-ON - CONTROLS - CHECKS - ADJUSTMENTS - START-UP




All the functions/operations relating to the operating modes must always respect the safety measures and the prescriptions to protect against residual risks.




During the working cycle, it is essential to respect the safety measures and prescriptions to protect against residual risks.

1.2.1. START-UP

Insert the pneumatic supply connector in the machine input.



If there is a filter unit (optional accessory), insert the pneumatic supply connector in the filter unit input.



Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- ☐ Disconnect main air supply from machine
- ☐ Release “PLV” switch to “off” (page 7 – figure A)
- ☐ Make sure foot pedal is away from any type of activation

1.2.1. MECHANICAL ADJUSTMENTS / MAINTENANCE



Carry out the operations below using only the tools supplied with the machine.



Below there is a list of all the adjustment and control interventions to be carried out during the production cycle, and which can be performed by the machine operator, in accordance with the indications given. It is essential to respect the safety measures and prescriptions to protect against residual risks.

Inserting the v-nails in the magazine
Insert the v-nails in the following way:

1. turn the PL valve (A) to the OFF position;



(Figure A)

2. the v-nail pusher will open;
3. insert the v-nails in the magazine (B), making sure the sharp part (glue edge side) is facing upwards, and the is positioned as in the photo;
4. turn the PL valve back to the ON position.



Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- ☐ Disconnect main air supply from machine
- ☐ Release "PLV" switch to "off" (page 7 – figure A)
- ☐ Make sure foot pedal is away from any type of activation

Replacing the magazine

To use v-nails of a different size, you must replace the magazine.


This is a simple operation:

Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- ❑ Disconnect main air supply from machine
- ❑ Release “PLV” switch to “off” (page 7 – figure A)
- ❑ Make sure foot pedal is away from any type of activation



1) Turn the PL valve (A) to the OFF position



2) If necessary, to get past the locking knob of the adjustable fence unit, lift the hold down vertical pad by pulling the plunger pin knob



3) Press the red button to move the carriage beyond the upper end stop



) Take out the magazine



) Insert the new magazine, pressing it down



) Push the magazine right in, until it is locked in place



) Raise the carriage release knob to bring it back within the range of the end stops



) Press the red button again, to bring the carriage back within the range of the end stops, then reposition the hold down vertical pad

Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- ☐ Disconnect main air supply from machine
- ☐ Release "PLV" switch to "off" (page 7 – figure A)
- ☐ Make sure foot pedal is away from any type of activation

Aligning the nail head

The operation to align the nail head with the driver and the magazine is necessary at times due continuous operation, because the components themselves may become worn, and because of jamming during driving.

To align the nail head, proceed as follows:

Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- ☐ Disconnect main air supply from machine
- ☐ Release "PLV" switch to "off" (page 7 – figure A)
- ☐ Make sure foot pedal is away from any type of activation



1) Loosen the 5 mm Allen screw that fixes the nail head in place



2) Remove the nail head



3) Loosen the screws that fix the L support




4) With the driver up, bring the L support near the driver and tighten the screws



5) Bring the magazine near the L support by loosening the two M magazine locking screws



6) Check the V-nail magazine and the L support are perfectly aligned



) Insert a v-nail in the magazine, resting it against the L support to check that the v-nail wings are perfectly inserted in the guide



) Re-assemble the nail head



) Insert a v-nail strip in the magazine, then activate the inserting of the v-nails (**make sure operator hands, clothing, vertical frontal clamp are completely away from driver test area**) (with no frames inserted) to ensure v-nails are correctly ejected

Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- ☐ **Disconnect main air supply from machine**
- ☐ **Release “PLV” switch to “off” (page 7 – figure A)**
- ☐ **Make sure foot pedal is away from any type of activation**

Adjusting, aligning and tilting the fences


To check the correct positioning for frames at 90°, you can request from AMP the transparent fence alignment tool (code #T757), on which the alignment trueness is indicated by an etched line.

Position the fence tool up against the limit stop, then use the handle to bring the nail head down as far as possible, checking that the middle of the nail head is aligned with the fence tool line.




Another way of aligning the fences is to use a reference frame corner with a very precise cut at 90°, 120° or 135°. Position the frame corner up against the limit stop of an angle gauge, then use the handle to bring the nail head down as far as possible, checking that the middle of the nail head is aligned with the cut of the frame.

Repeat the operation with the other fence.



To correct the angle of the fences, loosen the 4 fixing screws and adjust the position (taking advantage of the length of the slots), then retighten the screws.




Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- ☐ Disconnect main air supply from machine
- ☐ Release “PLV” switch to “off” (page 7 – figure A)
- ☐ Make sure foot pedal is away from any type of activation

The mouldings may have a slightly tilted outer edge. To improve the contact with the moulding profile, the edge of the fences can also be tilted.

Turn the knobs, as shown in the photo alongside, to tilt the edges.



Adjusting the angle of the fences

To alter the angle, you must replace the fixed fences support with another that has the required angle.


The 2 knob tilting fence for 90° points (A) (90°-sided frame) is supplied as standard.

By installing fence (B optional), the machine can be used for 120° points (120°-sided frames).

By installing fence (C optional), the machine can be used for 135° points (135°-sided frames).

Note: the declared machine stroke (200mm) is determined using the standard 90° fences.

If fences with different angles (120° and 135°) are used, the stroke will be reduced due to the greater dimensions.



Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- ☐ Disconnect main air supply from machine
- ☐ Release “PLV” switch to “off” (page 7 – figure A)
- ☐ Make sure foot pedal is away from any type of activation

To replace the fixed fences support, you must loosen the 2 Allen screws.



Take out the screws, then remove the fixed fences support.

To assemble the new fences, follow this procedure in reverse and retighten the 2 Allen screws.



Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- ☐ Disconnect main air supply from machine
- ☐ Release “PLV” switch to “off” (page 7 – figure A)
- ☐ Make sure foot pedal is away from any type of activation

If the fixed fence has no end stops, you must disassemble these from the old gauge and transfer them to the new one. To do this, just loosen the screws shown in the figure.



To disassemble the adjustable fences unit, just loosen the knob.



After loosening the knob, remove the slide in the lower part of the working bench.



Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- ☐ Disconnect main air supply from machine
- ☐ Release "PLV" switch to "off" (page 7 – figure A)
- ☐ Make sure foot pedal is away from any type of activation

Adjusting the height of the hold down vertical pad, and replacing it

To adapt the buffer position to the thickness of the frame, proceed as follows:

1. pull the plunger pin knob outwards;
2. raise or lower the perforated rod, depending on your needs;
3. release the plunger pin knob to lock the rod in place.



To replace the pad, you must loosen the screw that fixes it to the rod, then remove it by pulling it downwards.



Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- ☐ Disconnect main air supply from machine
- ☐ Release "PLV" switch to "off" (page 7 – figure A)
- ☐ Make sure foot pedal is away from any type of activation

Once the new pad or the magnetic pad support has been inserted, retighten the Allen screw.



Position the magnetic accessories under the pad and check it is in the right position by inserting a frame to be joined.




Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- ☐ Disconnect main air supply from machine
- ☐ Release “PLV” switch to “off” (page 7 – figure A)
- ☐ Make sure foot pedal is away from any type of activation


Adjusting the frontal clamp rod and adjustable fences unit

Depending on the dimensions of the frames to be assembled, you must make a series of adjustments regarding the frontal clamp rod and adjustable fences unit - the procedure is described below:



Wide Profile Moulding

If the frame is wide, the adjustable fences unit must be moved towards the outer part of the machine




Narrow Profile Moulding

If the frame is narrow, the adjustable fence unit must be moved towards the frontal clamp rod.



Adjusting the Fence

To slide the adjustable fences unit on the working bench, loosen the knob by turning it counter-clockwise then, when the fence is in the right position; lock it in place by turning the knob clockwise



Adjusting the Frontal Clamp

To position the frontal clamp rod, loosen the knob (if using) and remove it, then move the perforated rod to the required position and lock in by remounting the knob (optional)

The optimum gap to leave between the frontal clamp rod and the moulding frame is 10 millimeters (1/2")

Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- ☐ Disconnect main air supply from machine
- ☐ Release "PLV" switch to "off" (page 7 - figure A)
- ☐ Make sure foot pedal is away from any type of activation

Adjusting the pressure of the mouldings clamping devices

The procedure for adjusting the pressure of the vertical and horizontal mouldings clamping devices is described below.
The work pressure must be suitable for the hardness of the mouldings to be joined.

The pressure adjustment allows you to vary the locking force of the mouldings to be joined.
Adjust the locking pressure in such a way as to avoid crushing or damaging the surface of the material to be joined, but make sure the force of the driver for inserting the v-nail does not cause the moulding itself to rise.

The harder the material to be joined, the greater the pressure that can be applied to the clamping devices.
To correctly assemble the mouldings, you must always check they do not rise when the v-nails are being inserted.

An excessively low work pressure may mean the v-nail is not fully inserted in the frame.
The work pressure is adjusted via the special regulator on the pneumatic panel (A), next to the pressure gauge.
To change the work pressure, proceed as follows (B):

1. raise the knob by about 3-4 mm;
2. turn it clockwise to increase the pressure, or counter-clockwise to reduce the pressure;
3. press the knob to lock it in place.

The following work pressure levels are recommended:

Type of wood		Pressure	PSI
Soft	samba, etc.	2.5 bar	36psi
Medium	ramino, etc.	3 bar	43psi
Hard	oak, etc.	3.5 bar	50psi

For 10 mm v-nails, increase the pressure/psi by 10% .
When inserting several stacking v-nails, increase the work pressure/psi by 10-15% .



Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- ☐ Disconnect main air supply from machine
- ☐ Release “PLV” switch to “off” (page 7 – figure A)
- ☐ Make sure foot pedal is away from any type of activation

Adjusting the tilt of the working bench

Depending on the operator's needs, the working bench can be tilted.

To adjust it, proceed as follows:

1. loosen the handle beneath the working bench (A);
2. slowly rotate the surface until it is in the required position;
3. retighten the handle.



Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- ☐ Disconnect main air supply from machine
- ☐ Release "PLV" switch to "off" (page 7 – figure A)
- ☐ Make sure foot pedal is away from any type of activation

Adjusting the counter-balancing system

The machine is equipped with a carriage counter-balancing system.


When you work with the machine tilted, the pressure applied by the counter-balancing system must be adjusted on the basis of the tilt degree.

If the calibration is correct, the carriage should remain in place (not falling towards the lower end stop) when the carriage-moving handle is released. To calibrate the counter-balancing system, proceed as follows:


1. tilt the machine as far as the required position;
2. adjust the knob (A) of the pressure regulator to vary the pneumatic pressure inside the cylinder (B) connected to the carriage;
3. move the handle along its stroke and check the counter-balancing is correct.

Note:

An excessively high pressure tends to push the carriage towards the rear part of the machine. An excessively low pressure is unable to support the carriage, which therefore falls towards the front part of the machine (towards the frontal clamp rod).



To adjust on the pressure regulator, raise the knob to release it, and then turn it clockwise to increase the pressure or counter-clockwise to reduce it; when the value is correct, lower the knob to lock it in place.



Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- ☐ Disconnect main air supply from machine
- ☐ Release "PLV" switch to "off" (page 7 – figure A)
- ☐ Make sure foot pedal is away from any type of activation


Adjusting the v-nail positioning

The machine is equipped with an adjustable v-nail expulsion unit, assembled on a manually-commanded carriage.

The maximum carriage stroke is 200mm (8"). Various insertion points can be established within this stroke (A).

This picture shows v-nails inserted along the miter joint;

A



2 or more v-nails can be inserted in the same point, depending on the thickness of the frame.

Apart from blocking the mouldings, a braking system also ensures the perfect locking of the driving unit (nail head), which allows the multiple insertion of v-nails in a single position.

B




To allow the machine to produce top quality miter joints with a wide variety of materials, different types of v-nails are needed.

The v-nails can be classified into three different groups:

1. SPT for soft woods and plastic;
2. HPT for medium-hard woods;
3. HDF for hard woods or MDF.

To obtain the best results in the quality of the miter joints created, observe the following guidelines:

- avoid inserting v-nails near the end of the miter joint; the minimum recommended distance from the outer edge is at least 10mm (3/8");
- when creating a miter joint with just one v-nail, position the v-nail on the center line of the frame;
- when you want to insert at least 2 v-nails for each miter joint, insert the outer v-nail 1/3 from the outer edge, and the inner v-nail 1/4 from the inner edge.



Caution: Operator is to ensure to do one or all of the following during any machine adjustment:


- Disconnect main air supply from machine
- Release "PLV" switch to "off" (page 7 – figure A)
- Make sure foot pedal is away from any type of activation

Positioning the side handle

The machine can work with the handle on the right side or the left. If you want to change the current position, proceed as follows:

Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- ❑ Disconnect main air supply from machine
- ❑ Release “PLV” switch to “off” (page 7 – figure A)
- ❑ Make sure foot pedal is away from any type of activation



- 1) Remove the 2 screws that fix the lever to the carriage.



- 2) Take the 3 tubes out of their connectors, noting the exact position of each one (black, white, red)



- 3) Take the handle out of the machine



-) The disassembled handle looks like this, with the 3 tubes (black, white, red)



-) Insert the handle on the other side



-) Fix the handle to the carriage by means of the 2 screws, and then reconnect the 3 tubes in the correct positions, as before

Caution: Operator is to ensure to do one or all of the following during any machine adjustment:

- ☐ Disconnect main air supply from machine
- ☐ Release "PLV" switch to "off" (page 7 – figure A)
- ☐ Make sure foot pedal is away from any type of activation

1.3. OR C CLE



During normal production, the machine must be used exclusively to work the products of wood, MDF/HDF and polystyrene as described in manual.

During the working cycle, it is essential to respect the safety measures and prescriptions to protect against residual risks.



For details of the functions of each command and information device, refer to the Layout and description of the command and signaling devices given in the pneumatic diagram enclosed with this manual.

Check the v-nail magazine is full, the nail head is correctly assembled, and the adjustments have been made.




Insert the pneumatic supply tube directly in the machine (or in the filter unit, if present).



The machine is ready to miter joint. Insert the moulding on the right-hand stop, then bring the left-hand one up next to it.



Press the pedal for the horizontal locking with the frontal clamp rod.



Move the nail head carriage by means of the handle, press the button lightly to block the frames with the buffer, the press fully down to insert the v-nail.

Release the button and move the carriage to the next position, ready to insert another v-nail.



1. . DEACTI ATION




After you have finished using the machine, it must be deactivated.
The pneumatic tube that powers it must be disconnected.



The pneumatic actuators may have accumulated energy, and must therefore be discharged to avoid any unexpected and dangerous activation.

If the filter unit is present, rotate the knob to discharge the machine system, and then disconnect the pneumatic supply tube.




Caution: Operator is to ensure to do one or all of the following during any machine adjustment:


- ☐ Disconnect main air supply from machine
- ☐ Release “PLV” switch to “off” (page 7 – figure A)
- ☐ Make sure foot pedal is away from any type of activation

1. MECHANICAL SCHEMATIC


Main Assembly s

Alfamacchine







POS.	CODE	DESCRIPTION
1	M30100001	PIANO M144
2	735630006	MICROREGOLATORE BIT 1/8
3	732140001	VALVOLA 0ALF M5 PLV
4	734230004	MANOMETRO 0-10 BAR 1/8
5	732140005	VALVOLA PULSANTE
6	M29000004	CARCASSA M144
7	384200020	SUPPORTO BLOCCAGGIO ORIZZONTALE
8	753320012	POMELLO ARRESTO
9	M29100012	BLOCCAGGIO ORIZZONTALE M144
10	240450044	SERBATOIO
11	735630004	MICROREGOLATORE 0-4 1/8
12	365010130	TAPPO NYLON D.13
13	M29100011	ARRESTO
14	M29000015	ASTA FOGLIA
15	365210335	TARGHETTA CRUSCOTTO M144
15	365210336	TARGHETTA CRUSCOTTO VN144
16	M30100048	INDICE
17	366710106	RIGHELLO SQUADRA MM-INCH
18	366710105	RIGHELLO MM-INCH
19	336100070	RONDELLA INDICE
20	753170008	MANIGLIA M8x25
21	753320001	POMELLO A LOBI M6x12
22	734230002	MANOMETRO 0-4 BAR 1/8
23	M30100009	SUPPORTO SQUADRA
24	M29100004	SQUADRA 2 POMELLI M144
25	M30100010	SLITTA BLOCCAGGIO SQUADRA
26	M30100080	VOLANTINO A LOBI M12x22
27	710100072	VITE TCEI M6x10
28	718100006	RONDELLA M12
29	366210030	VITE AZIONAMENTO ASTA FOGLIA



POS.	CODE	DESCRIPTION
1	M30100004	PIASTRA SLITTA M144
2	M30100006	MANICOTTO ASTA
3	705050024	SEEGER I35
4	740550084	MANICOTTO KH2540
5	394950570	TESTINA MC
6	M30100011	SUPPORTO L M144
7	732440003	VALVOLA
8	M30100039	SUPPORTO CILINDRO DI BILANCIAMENTO M144
9	334000490	ASTA MC
10	M22000004	COMPLESSIVO FRENO M144
11	M30000009	SUPPORTO CILINDRO ARRESTO
12	753750017	CILINDRO ARRESTO
13	M30100002	BLOCCHETTO ANTERIORE ASTE
14	M30100003	SPESSORE BLOCCHETTO
15	M30100005	BLOCCHETTO POSTERIORE ASTE
16	M30100012	ANELLO ARRESTO
17	M29100008	CILINDRO BILANCIAMENTO M144
18	M30100076	SUPPORTO ASTA
19	710100061	VITE TCEI M5x70
20	710100015	VITE TCEI M4x60
21	710100120	VITE TCEI M8x50
22	710100119	VITE TCEI M8x45
23	710100147	VITE TCEI M6x55
24	710100093	VITE TCEI M6x20
25	710100076	VITE TCEI M6x18
26	710100080	VITE TCEI M6x30
27	710100082	VITE TCEI M6x40
28	352400010	TESTA CILINDRO
29	M29100022	MARTELLETTO COMPLETO M144
30	352200260	COPPA




POS.	CODE	DESCRIPTION
1	M30100054	MAGAZZINO
2	M30100055	CARICATORE H15
3	M30100056	CARICATORE H12
4	M30100057	CARICATORE H10
5	M30100058	CARICATORE H7
6	M30100059	CARICATORE H5
7	M29100020	CILINDRO SPINGIPUNTI M144
8	M30000003	SUPPORTO CILINDRO SPINGIPUNTI M144
9	710100046	VITE TCEI M5x18
10	718100002	RONDELLA M5
11	753320014	TESTA A SNODO RF4
12	710100006	VITE TCEI M4x16
13	718100001	RONDELLA M4
14	M30100065	PERNO MOVIMENTAZIONE
15	715650002	DADO M5
16	753320013	PRESSORE M5
17	710100042	VITE TCEI M5x10
18	M30100070	SUPPORTO PRESSORE
19	732630003	REGOLATORE DI FLUSSO
20	734230002	MANOMETRO 0-4 BAR 1/8
21	735630004	MICROREGOLATORE 0-4 1/8
22	710100002	VITE TCEI M4x8
23	M30100082	INVITO MAGAZZINO
24	710100044	VITE TCEI M5x14
25	714300063	GRANO M4x6
26	M30100066	DENTE SPINGIPUNTI
27	M30100079	PERNO CURSORE
28	714300003	GRANO M4x4
29	714300073	GRANO M5x8
30	M30100062	CURSORE SPINGIPUNTI
31	M30100078	CAMMA ROTAZIONE DENTE



Optional Accessory

Item M220000003



Ref.	Code	Description	quantity
1	1 10001	mm Flat washer	1
2	33 1000 0	mm Shoulder washer	3
3	31 001	mm 2 mm Turn Handle	1
	1010011	mm 30mm Bolt	
	10100122	mm 0mm Bolt	
	M2 00000	elded Base	1
	M2 00000	Tilting Frame	1
	3 0020	10mm Machine Levelers	
	M2 000012	elded Upright	1
10	M2 000011	Upright Ad . Extension (Right)	1
11	M2 000010	Upright Ad . Extension (Left)	1
12	103 0 30	Plastic End Cap, 0 30	
13	1 3000 2	12mm Set Screw	
1	N/A	mm Allen wrench	1

1. PNEUMATIC SCHEMATIC

